



















A X1  Base (1&2)	H X1  Backrest Support	I X1  Backrest
B X1  Lumbar Pillow	J X1  Cushion	
C X2  Armrest (L & R)	K X2  Guide Rail	L X1  Allen Key
D X1  Footrest	M X1  armrest cushion wrench	N X6  Guide Rail Screws
E X1  Tilt Mechanism	O X6  Armrest Screws	P X4  Tilt Mechanism Screws
F X5  Caster	R X1  End screw of the footrest steel pipe	Q X4  Screws at the bottom of backrest support
G X1  Cylinder & Cover	S X4  Screws on top of backrest support	T X4  armrest cushion screws

